


Turntable setup

1. Place the platter on top of the center spindle.
2. Wrap the belt around the pulley and the platter.
3. Connect the AC adapter to your Orbit's power jack.
4. Slide the dust cover onto its hinges.
5. Connect your Orbit to your stereo using the included RCA cables. Remove stylus cover.



Video setup guide & additional resources
available at uturnaudio.com/orbit-setup

Stereo setup

If using a built-in phono preamp: See back page.

If using a separate phono preamp: Connect your Orbit to the RCA input on your phono preamp. Then connect the preamp to powered speakers or an amp.

If using a stereo receiver: Connect your Orbit to your receiver's RCA "phono" input.

Start spinning

1. Make sure your belt is positioned correctly (top pulley groove for 33 RPM, lower groove for 45 RPM).
2. Turn the power switch on and then gently lower the stylus (needle) onto the outer groove of your record.
3. When the record is finished, gently place the tonearm in the rest. Turn your Orbit off when not in use.

Helpful tips

- Place your turntable on a flat surface that is away from heat and direct sunlight. Do not put your turntable on the same surface as your speakers.
- In order to prevent interference issues, keep your turntable, preamp, and RCA cables away from other electronic components and cables.
- Only touch the center label and outer edge of your records. Never stack your records, and keep them out of direct sunlight.
- Leave the dust cover closed whenever possible. Use a record brush to keep your vinyl free of dust. Remove any debris that may accumulate on the stylus.

Two year warranty


U-Turn Audio warrants the Orbit Turntable against defects in materials and workmanship under normal use for a period of two (2) years from the date of purchase by the original end-user. If a defect occurs during the warranty period, we will repair the defective product free of charge.

If you think you need warranty service, please contact us first. If your turntable is sent back to us without a Return Merchandise Authorization (RMA), it will be returned to sender without repair. To obtain an RMA, please email support@uturnaudio.com or call 781-451-1445. For our full warranty policy and instructions for obtaining an RMA, please visit uturnaudio.com/warranty-and-return-policy.

Orbit Cue (optional)

The silicone-damped Orbit Cue helps you safely and precisely cue your records.

To use: Raise lever and place the tonearm onto the Cue platform. Lower lever to place stylus onto record.



Built-in phono preamp (optional)

If you have a built-in phono preamp, you can connect your Orbit directly to powered speakers or an amplifier using the included RCA cables.

To use: The built-in preamp is set to “on” out of the box. Simply connect to powered speakers or an amp using the included RCA cables.

If you want to use an external preamp, press the “preamp bypass switch” to disable the built-in preamp. The preamp is disabled when the LED is off.

